Self-Stick Door/Window Alarm

OWNER'S MANUAL — Please read before using this equipment.

Your RadioShack Self-Stick Door/Window Alarm is a convenient and easy-to-use security device. You can easily install the alarm on almost any smooth door surface or glass window. If the alarm senses an abrupt shock or vibration, it sounds a 120-dB alarm to warn you and scare off possible intruders.

Its features include:

Selectable Sensitivity Switch — lets you set the alarm's sensitivity higher or lower.

Red Warning Label — can be seen through window to show that your home is protected.

Automatic Reset — automatically reset the alarm in about 30 seconds after the alarm is activated.

Intruder Memory Indicator — warns you that the alarm has been activated.

PREPARATION

Installing the Battery

The alarm requires a 9V battery for power (not supplied, available at your local RadioShack store).

Caution: Use only a fresh battery of the required size and recommended type.

Follow these steps to install the battery:

1. Use a Philips screwdriver to loosen the screw in the battery compartment and slide off the cover.
2. Snap a 9V battery into the connector in the battery compartment and place the battery in the compartment.
3. Replace the cover and secure it with the screw.

Warning: Dispose of old batteries promptly and properly. Do not burn or bury them.

Caution: If you do not plan to use the alarm for a month or more, remove the battery. Batteries can leak chemicals that can destroy electronic parts.

Note: When the green low battery indicator flashes, replace the battery.

Installing the Alarm

Choose a smooth, clean mounting surface, then peel off the protective film on the back of the alarm and firmly press the alarm against the surface.

OPERATION

Warning: The alarm is very loud. Prolonged exposure to the siren in an enclosed area may cause permanent hearing impairment or loss.

1. To turn on the alarm, slide the cover at the upper front of the alarm upward, then turn **ON OFF** to **ON**. The red indicator flashes once.
2. Select the alarm's sensitivity by sliding **HI/LOW** to **HI** or **LOW**. When the alarm senses an abrupt shock or vibration, it sounds a 120-dB alarm for about 30 seconds. The red indicator lights and remains lit to warn you that the alarm has been activated.

   Notes:

   - If the alarm is triggered again within two minutes of the first alarm and while the intruder light is still on, the subsequent alarms may be shorter than 30 seconds.
   - To reset the intruder memory indicator, simply turn alarm off, then on.

CARE

To enjoy your RadioShack Self-Stick Door/Window Alarm for a long time:

- Keep the alarm dry. If it gets wet, wipe it dry immediately.
- Use and store the alarm only in normal temperature environments.
- Handle the alarm gently and carefully. Do not drop it.
- Keep the alarm away from dust and dirt.
- Wipe the alarm with a damp cloth occasionally to keep it looking new.

RadioShack®
www.radioshack.com℠

© 2000 Tandy Corporation.
All Rights Reserved.
RadioShack and RadioShack.com are trademarks used by Tandy Corporation.

Modifying or tampering with the alarm's internal components can cause a malfunction and might invalidate its warranty. If your alarm is not performing as it should, take it to your local RadioShack store for assistance.

SPECIFICATIONS

Power Source	1 × 9V Battery
Current Drain	Standby Mode: < 0.1 mA Alarm Mode: < 100 mA
Alarm Sound Level	>118 dB
Battery Life (Standby Mode)	208 days
Operation Temperature	32 through 113° F (0 through 45° C)
Storage Temperature	–4 through 140° F (–20 through 60° C)

Specifications are typical; individual units might vary. Specifications are subject to change and improvement without notice.

Limited Ninety-Day Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, 200 Taylor Street, 6th Floor, Fort Worth, TX 76102

We Service What We Sell *12/99*

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

49-407
04A00
Printed in China